

System Requirements for PCI-Express Frame Grabber

Important installation notes

- The PCI-Express Frame Grabber is only compatible with desktops that have an available full height PCI express slot. Dell systems are not compatible with the frame grabber.
- Install all necessary drivers in a standalone system without internet connection or connection to any server.
- Installation should be with full administration privileges.
- Disable the antivirus system temporary during the installation.
- Install and use the driver version 10.3.0.
http://www.optiliaindustrial.eu/software/Blackmagic_Desktop_Video_Windows_10.3.zip

Officially supported computers by Optilia

- **Station:** HP ProDesk Core i5 or i7

System requirements

The table below displays specifications recommended for the computer. However Optilia does not guarantee it will work without any issues if the computer is not registered in the officially supported list above.

Component	Recommended specification
CPU	Intel Core i5 2.8GHz or higher
Operating System	Windows 7 Professional (64 bit), Windows 8.1 (64 bit), Windows 10 (64 bit) Windows Enterprise is not supported!
Memory	Minimum: 2 GB Recommended: 4 GB or higher
Hard disk	Minimum: 200 GB of Free Space Recommended: 500 GB of Free Space
Display	Minimum: Laptop: 15.6" / 1600x900 (HD+) PC: 22" /1920 x 1080 (Full HD) Recommended: Laptop: 15.6" - 17.3" / 1920x1080 (Full HD) PC: 24" /1920 x 1080 (Full HD)
Other	Minimum: 1 x Full height PCI express slot Recommended:: 3 x USB 2.0 port, 1 x full height PCI express slot